



NOTES:

DAVIT SURFACE MUST BE CLEAN AND FREE OF ALL RUST AND OTHER CONTAMINANTS

USE LARGEST SHEETS OF UNCURED NEOPRENE POSSIBLE. WHEN POSSIBLE, A HOLE SMALLER THAN THE PENETRATION SHOULD BE CUT IN THE CENTER OF THE SHEET OF NEOPRENE AND THE SHEET PULLED DOWN OVER THE DAVIT.

CUT A SLIT OR "X" INTO THE NEOPRENE SHEET DIRECTLY OVER THE BOLT HEADS TO ALLOW EMBEDDING/FORMING TIGHTLY AROUND BOLT HEAD.



Monolithic Membrane
6125-FR
ROOFING SYSTEMS

AMERICAN HYDROTECH, INC.

TYPICAL DAVIT DETAIL

3"=1'-0"

R-10